



## Micathermic Radiator

---

### Important safety precautions

These instructions should be read carefully and left with the user of the product for future reference.

#### BEFORE USE

You must inspect the appliance including its cable and plug for any signs of damage. If the product is damaged, please do not use it and contact London Cool immediately.

#### OPERATION

- 1) Plug the mains lead into a 13 amp mains socket. If connecting via an extension lead, please make sure the lead is rated at 13 amps or more and that it is fully unwound.
- 2) Switch the appliance on at the mains socket.
- 3) Turn on the rocker switch at the side of the appliance adjacent to the mains cable entry. The display will light briefly.
- 4) Press the 'On' button to switch the appliance on.
- 5) The digital display will show the room temperature. The up and down arrows can be used to select full power or half power. This is indicated by the segments to the right of the flame symbol. Small segment = half power, both segments = full power.
- 6) To set the thermostat, press the TEMP down, then press the up or down arrow buttons to change the target temperature. The thermometer symbol will illuminate, and the digital display will flash, showing a target temperature. After 5 seconds the display will stop flashing and return to displaying the room temperature.
- 7) To set the timer, press the TIMER button. The clock symbol will illuminate. Then use the up and down arrow buttons to set the number of hours for which the heater is to run before automatically switching it off.
- 8) Unplug the appliance from the mains when not in use. The cable can be wrapped around the plastic cable tidy on the front panel.

### Product Safety

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Place the appliance on a firm flat surface.
- Ensure that there is at least 300mm (1') between the sides of the appliance and any flammable materials.

- Ensure that there is at least 900mm (3') from the top of the appliance and any flammable materials.
- Do not place on soft surfaces.
- Do not cover the appliance.
- Do not use outdoors.
- Do not use in immediate surroundings of a bath, a shower or a swimming pool.
- Do not use in bathrooms, or in wet locations.
- Do not place the mains lead beneath a carpet or rug.
- Do not use the appliance in locations where paint, petrol, or other flammable liquids are used or stored.
- Do not use the appliance without the feet attached.
- Do not locate the appliance immediately below a socket outlet.
- Do not insert any object into the heater through the grilles. This may damage the heater or result in overheating or electric shock.
- Not suitable for use in boats, caravans or similar locations.

### General safety requirements

Domestic wiring must be tested periodically by a qualified electrician at least once every 10 years or at every change of occupancy. For office and retail premises, and buildings such as village halls, the wiring must be inspected at least once every 5 years.

It is recommended that all buildings be fitted with smoke alarms (it is mandatory for new buildings).

### Fault finding

If the appliance is not operating, proceed as follows:

- Check the mains plug is firmly in the socket and that the socket is switched on.
- Check that at least one of the power control switches is switched on.
- The appliance also has an overload protection device to prevent overheating. If this operated, disconnect the appliance from the mains supply, and remove any objects on or adjacent to the appliance that could have caused the overheating. Wait 10 minutes, and re-connected to the mains supply.
- If the appliance still does not function or the overload protection device operates again, consult an authorised service agent.
- The appliance is also fitted with a tip-over switch which will disconnect the power if it falls over. If it does not operate, make sure that it is standing upright.